



Öar (Islands) - Light Plot
Ingrid Olterman Dance



Technical contact: Christian Farcher
Email: Christian@AScentofMusic.se
Phone: +46 (0)701 43 01 40



Island 1




Island 2


AUDIENCE

A
U
D
I
E
N
C
E

A
U
D
I
E
N
C
E



Entrance



Island 3

Fixture Patch

Head No	DMX	Position	Hang	Manufacturer	Model	Mode
1				---	Fresnel	dimmer
2				---	Fresnel	dimmer
3				---	Fresnel	dimmer
4				---	Fresnel	dimmer
5				---	Fresnel	dimmer
6				---	Fresnel	dimmer
7				---	Fresnel	dimmer
8				---	Fresnel	dimmer
9				---	Fresnel	dimmer
10				---	Fresnel	dimmer
11				---	Fresnel	dimmer
12				---	Fresnel	dimmer
20				---	Fresnel	dimmer
21				---	Fresnel	dimmer
30				ETC	s4 jr	dimmer
31				ETC	s4 jr	dimmer
40				ETC	s4 jr	dimmer
41				ETC	s4 jr	dimmer
42				ETC	s4 jr	dimmer
50				ETC	s4 jr	dimmer
51				ETC	s4 jr	dimmer
52				ETC	s4 jr	dimmer
60				ETC	s4 jr	dimmer
61				ETC	s4 jr	dimmer
62				ETC	s4 jr	dimmer
101	02-001			Robe	Rob300LEDWash	Mode 1
102	02-038			Robe	Rob300LEDWash	Mode 1
103	02-075			Robe	Rob300LEDWash	Mode 1
104	02-112			Robe	Rob300LEDWash	Mode 1

